

PRODUCT DATA

Castrol Foam Air Filter Oil

PRODUCT DESCRIPTION

Castrol Foam Air Filter Oil has been specifically formulated for application to “ wet type “ foam air filters fitted to four stroke and two stroke engines.

Through a carefully selected designed balance of selected base oils and additives, the product provides excellent performance in preventing airborne dirt and abrasive particles from passing through the fuel intake system into the combustion chamber.

Castrol Foam Air Filter Oil has now been packaged in an aerosol for improved, easier application.

PRODUCT APPLICATION

Directions For Use:

Castrol Foam Air Filter Oil is designed for use with oiled foam elements.

Wear solvent resistant gloves when using **Castrol Foam Air Filter Oil**.

1. Ensure the foam filter is clean. To clean, wash a dirty filter in solvent (for example kerosene or distillate) to remove oil and dirt. Squeeze out any remaining solvent carefully, taking care not to damage the foam element.
2. Spray **Castrol Foam Air Filter Oil** liberally to both inside and outside of the clean foam element. Work into the foam until it has become saturated. Squeeze out the excess oil carefully, taking care not to damage the element. Allow to dry in a well ventilated area before reassembling to the motor.
3. Service the foam air filter regularly, Particularly when unit has been used in dirty or dusty conditions.

Note : If filter is washed with degreaser and then with water, remove as much water as possible by shaking or squeezing between absorbent material before applying **Castrol Foam Air Filter Oil**. Extra effort (kneading) will be required to completely saturate a filter that still contains some moisture.

Caution – Keep out of reach of children.

Caution and Safety Directions :

Contents under pressure . Do Not puncture or incinerate can, even when empty. Contents **Highly Flammable** – always use in a well ventilated area, do not smoke when using the product and do not apply to either hot engine parts or parts that are likely to heat up during use (eg. Exhaust manifolds). Do not spray near sources of combustion or ignition. Avoid contact with skin and eyes. Avoid inhaling mist or vapours. Deliberate concentration or inhalation of vapours can be fatal. Store product at a temperature above 5°C and below 50°C. Keep out of direct sunlight.



HEALTH, SAFETY & ENVIRONMENT

Castrol Foam Air Filter Oil is considered hazardous in accordance with the HSNO Act for Flammable Aerosol – 2.1.2A.

However, in line with safe handling practices, it is recommended that the handling instructions outlined in the Castrol Material Safety Data sheet be followed.

Spillage

- Small:** Soak up using an inert mineral adsorbent such as Castrol MOP S and dispose of in the appropriate manner.
- Large:** Corrective action usually dictated by individual company safety procedures. Immediate containment and subsequent removal is essential.
- Disposal:** Oily materials must not be allowed to enter groundwater, watercourses, sewerage or drainage systems. Refer to local Waste Disposal Authority for legal requirements.

Product Removal

- Bare Metal Surfaces:** Remove with Castrol solvent cleaners or water based degreasers.
- Hand Cleaning:** Use any of the Castrol range of hand cleaners, e.g. CareClean Plus.
- Other Surfaces:** Contact the Castrol Technical Advice Line on 0800 10 40 60.

30/04/10

Although all reasonable care has been taken to ensure that the information contained in this publication is accurate as at the time of printing, such information is nevertheless liable to variation in the event of changes occurring subsequent to the date of printing it: the blend formulation, methods of storage, or due to the improper handling or application of any of the products referred to, or in the requirements of any specification or approval relating to any of the products.

For more information contact: Castrol NZ (A Business Division of BP Oil New Zealand Limited)
Technical Advice Line: 0800 10 40 60
Customer Service: 0800 CASTROL (227 876)

www.castrol.com/nz

